

FF7LWBIVACADA



32.25" x 23.63" x 23.25" (H x W x D)

Built-in ADA undercounter medical all-refrigerator for temperature stable medical storage, with interior basket drawers, internal fan, lock, and more

Highlights:

Medical grade all-refrigerator ideally suited for vaccine and pharmaceutical storage

Interior drawers ensure stored items are not exposed to room temperature when the door is open

Automatic defrost with an internal fan for stabilized cooling designed to stay within 2°C of set temperature

Product Features:

Improved temperature stability	Interior is designed to operate within 2°C of set temperature performance
ADA Compliant	32" height is designed to fit under lower ADA compliant counters
Interior basket drawers	Three slide-out wire baskets with plastic fronts offer convenient storage solutions while protecting stored items when the door is open
Digital thermostat	Electronic controls ensure precise and intuitive temperature management
High/low temperature alarm	Audible alarm sounds if the interior temperature rises or falls out of set range
NIST calibrated temperature display	Alarm includes NIST calibrated display of the current interior and high/low temperature
Self-closing door	Door closes automatically when opened at angles less than 90°
Access port with contact	Pre-installed probe with contact allows users to install their own monitoring equipment; customers can specify placement of the access port upon order
Hospital grade cord and plug	Secure three-pronged 'green dot' cord for added unit safety in high traffic settings

FF7LWBIVACADA Specifications:

Overview	
Height of Cabinet	32.0" (81 cm)
Height to Hinge Cap	32.25" (82 cm)
Width	23.63" (60 cm)
Depth	23.25" (59 cm)
Depth with Handle	25.13" (64 cm)
Depth with door at 90°	44.25" (112 cm)
Capacity	2.6 cu.ft. (74 L)
Defrost Type	Automatic
Door	White
Cabinet	White
US Electrical Safety	ETL
Canadian Electrical Safety	ETL-C
Amps	1.4
Voltage/Frequency	115 V AC/60 Hz
Weight	100.0 lbs. (45 kg)
Shipping Weight	105.0 lbs. (48 kg)
Parts & Labor Warranty	2 Years
Compressor Warranty	5 Years
Refrigerator Features	
Door Swing	RHD
Reversible	Factory Reversible
Thermostat Type	Digital
Fan Type	Interior and Exterior
Refrigerant Type	R600a
Refrigerant Amount	0.64oz.
High Side PSI	180.0
Low Side PSI	80.0
Level Legs Qty	4
Interior Drawers	Yes
Interior Drawers Qty	3
Temperature Range	2° to 8°C
Dimensions	
Interior Height	22.5" (57 cm)
Interior Width	17.25" (44 cm)
Interior Depth	15.0" (38 cm)

