

Improve business efficiency • Improve employee workplace safety • Improve patient care & management



Narcotic Cabinet - #181502

Omnimed Horizontal Mount Narcotic Cabinets are constructed of durable, heavy duty stainless steel and meet schedule 2 drug storage requirements. They have strong piano hinged doors and a two door, dual locking system to ensure content security. The outside door has a triple bolt wafer lock which opens to a second door secured by a flat key lock with a heavy gauge locking cam. Three extra keys are included for each unique lock. The ambit top of the cabinet lifts so that the unit can be flipped to accommodate left or right outer door access. Pre-drilled holes that are reinforced with stainless steel mounting discs ensure stable wall attachment. These units are warranted for life & include 1 year on the locks.

- Horizontal mount stainless steel double door cabinet
- Triple bolt wafer and flat key lock security 3 keys/lock included
- Ambi top for left/right outer door access
- Pre-drilled holes reinforced with stainless steel mounting discs
- Measures 8"H by 16"W by 8"D
- Unit Has lifetime Warranty (1 Year On Locks)

