

SCFF237



83.75" x 27.5" x 31" (H x W x D)

23 cu.ft. commercial reach-in all-freezer in complete stainless steel

Highlights:

Commercially listed to NSF standards

Stainless steel interior and exterior cabinet for true durability in high traffic commercial settings

Optimized forced air cooling for excellent temperature stability and uniformity with rapid recovery after door openings and product loading

Product Features:

Commercially approved	Commercial construction meeting UL commercial listing standards
Complete stainless steel construction	Interior and exterior are entirely constructed from stainless steel for lasting durability and easy cleanup
Forced air cooling	Top-mounted commercial fan ensures rapid temperature recovery
Automatic defrost with adjustable cycle defrost	Adjustable cycle defrost operation ensures the unit avoid temperature spikes and ice buildup
Self-closing door	Closes to save energy but will remain open when the door is opened at a 90° angle for easier loading
Open door alarm	Alarm will beep 3 times if the door is left open for 30 seconds, 5 times at 60 seconds, and will sound continuously if the door is open for more than 5 minutes
Temperature alarm	Visual and audible alarms alert if the interior temperature rises or falls out of set range
6 inch casters	6 inch casters
Microprocessor control panel	Digital controls with a large LED readout in Celsius or Fahrenheit for intuitive temperature management



SCFF237 Specifications:

Overview	
Height of Cabinet	83.75" (213 cm)
Width	27.5" (70 cm)
Depth	31.0" (79 cm)
Depth with door at 90°	56.5" (144 cm)
Capacity	23.0 cu.ft. (651 L)
Defrost Type	Frost-Free
Door	Stainless Steel
Cabinet	Stainless Steel
US Electrical Safety	UL
Canadian Electrical Safety	ULC
Sanitation	ETL-S
Amps	8.0
Voltage/Frequency	115 V AC/60 Hz
Weight	273.0 lbs. (124 kg)
Shipping Weight	293.0 lbs. (133 kg)
Parts & Labor Warranty	2 Years
Compressor Warranty	5 Years
Freezer	
Door Swing	RHD
Reversible	No
Interior Height	51.5" (131 cm)
Interior Width	23.5" (60 cm)
Interior Depth	27.0" (69 cm)
Shelf Type	Wire
Shelf Qty	4
Adjustable Shelves	Yes
Thermostat Type	Digital
Interior Light	Yes
Fan Type	Interior
Refrigerant Type	R290a
Refrigerant Amount	3.5 oz.
Wheels	4
Temperature Range	-10 to 25°F



