

FFAR121SSNZ



60.88" x 23.63" x 22.75" (H x W x D)

Commercially approved 10.1 cu.ft. Nutrition Center series all-refrigerator in white with front lock, and NIST calibrated digital temperature display

Highlights:

Commercially listed to NSF-7 standards

Thermometer is NIST calibrated in our ISO/IEC 17025:2017 laboratory

Digital temperature display and audible alarm allows easier temperature monitoring as recommended by JCAHO

Product Features:

Commercially approved	ETL-S listed to ANSI-NSF Standard 7
NIST calibrated temperature display	Thermometer provides continuous display of the current and high/low temperature to the nearest tenth of a degree, with a readout switchable from Celsius to Fahrenheit at the touch of a button
High/low temperature alarm	Audible alarm sounds if the interior temperature rises or falls out of set range
Stainless steel exterior	Door, cabinet, and kickplate feature complete stainless steel construction for lasting durability
Stainless steel interior	Full construction on interior walls and floor ensures improved sanitation
Digital thermostat	Electronic controls for more precise temperature management, with temperature readout and controls externally located for added convenience
Versatile display	Temperature display can be switched from Celsius to Fahrenheit at the touch of a button
Cantilevered shelves	Adjustable chrome shelves can be arranged in virtually any configuration for flexible storage
Factory installed lock	Keyed lock for secure interior

FFAR121SSNZ Specifications:

Overview	
Height of Cabinet	60.88" (155 cm)
Width	23.63" (60 cm)
Depth	22.75" (58 cm)
Depth with Handle	24.63" (63 cm)
Depth with door at 90°	45.0" (114 cm)
Capacity	10.1 cu.ft. (286 L)
Defrost Type	Automatic
Door	Stainless Steel
Cabinet	Stainless Steel
US Electrical Safety	ETL
Canadian Electrical Safety	ETL-C
Sanitation	ETL-S
Amps	1.7
Voltage/Frequency	115 V AC/60 Hz
Weight	140.0 lbs. (64 kg)
Shipping Weight	160.0 lbs. (73 kg)
Parts & Labor Warranty	1 Year
Compressor Warranty	5 Years
UPC	761101061153
Refrigerator Features	
Door Swing	RHD
Reversible	Yes
Shelf Type	Chrome
Shelf Qty	4
Adjustable Shelves	Yes
Thermostat Type	Digital
Fan Type	Interior
Refrigerant Type	R600a
Refrigerant Amount	1.66oz.
High Side PSI	270.0
Low Side PSI	105.0
Interior Light	Yes
Temperature Range	2° to 6°C
Dimensions	
Interior Height	50.25" (128 cm)
Interior Width	19.63" (50 cm)
Interior Depth	16.75" (43 cm)

Compressor Step Height	4.5" (11 cm)
Compressor Step Width	19.63" (50 cm)
Compressor Step Depth	4.5" (11 cm)

