

# ARS32PVBIADA



32" x 19.75" x 22.63" (H x W x D)

Performance series Pharma-Vac 2.83 cu.ft. ADA height solid door commercial all-refrigerator for the display and refrigeration of vaccines; designed for recessed or freestanding installation

### Highlights:

32" height fits under lower ADA compliant counters

Intelligent microprocessor digital temperature controller

Improved temperature accuracy with a separate temperature probe for continuous product readout to simulate stored product temperature

### Product Features:

Purpose-built design	Designed and purpose-built for pharmacy, medication, and vaccine applications to support meeting CDC/VFC guidelines
ADA Compliant	32" height is designed to fit under ADA compliant counters
Recessed or freestanding use	Versatile design allows recessed installation under counters or freestanding use
+/-1°C Variation	The published temperature variation is derived from the maximum deviation of an NTC sensor in a 1 oz. vial located nearest the chamber geometric center during a 24 hour test period
Commercial design	Meets UL-471 commercial standards
Adjustable temperature	Intuitive controls let you adjust the interior temperature between +2°C to +8°C
Temperature alarm	Visual and audible alarms alert if the interior temperature rises or falls out of set range
Remote alarm contacts	Electronic controller is equipped with a volt-free contact for alarm forwarding to an external remote system (contacts located in the external rear of the unit)
Automatic defrost with adjustable cycle defrost	Adjustable cycle defrost operation ensures the unit avoid temperature spikes and ice buildup

## ARS32PVBIADA Specifications:

Overview	
Height of Cabinet	32.0" (81 cm)
Width	19.75" (50 cm)
Width with Door Open	20.25" (51 cm)
Depth	22.63" (57 cm)
Depth with Handle	24.38" (62 cm)
Depth with door at 90°	40.0" (102 cm)
Capacity	2.83 cu.ft. (80 L)
Defrost Type	Automatic
Door	White
Cabinet	White
US Electrical Safety	ETL
Canadian Electrical Safety	ETL-C
Amps	0.75
Voltage/Frequency	115 V AC/60 Hz
Weight	102.0 lbs. (46 kg)
Shipping Weight	120.0 lbs. (54 kg)
Parts & Labor Warranty	2 Years
Compressor Warranty	5 Years
UPC	761101075297
Refrigerator Features	
Door Swing	RHD
Reversible	Yes
Shelf Type	Wire
Shelf Qty	4
Adjustable Shelves	Yes
Thermostat Type	Digital
Fan Type	Interior
Refrigerant Type	R600a
Refrigerant Amount	1.41oz.
High Side PSI	280.0
Low Side PSI	90.0
Interior Light	Yes
Temperature Range	2°C to 8°C
Dimensions	
Interior Height	24.0" (61 cm)
Interior Width	16.0" (41 cm)
Interior Depth	15.0" (38 cm)

Compressor Step Height	6.13" (16 cm)
Compressor Step Width	15.25" (39 cm)
Compressor Step Depth	5.5" (14 cm)

