

ACR45LCALSTO



31.5" x 19.5" x 24.75" (H x W x D)

Pharmacy Series ADA compliant 20" wide built-in undercounter all-refrigerator for vaccine storage, frost-free with a step-to-open door pedal, internal fan, external digital controls and NIST calibrated thermometer, and lock

Highlights:

Less than 32" high to allow installation under lower ADA compliant counters

Specially designed to meet current CDC/VFC vaccine refrigeration guidelines for convenient storage in pharmacies and other healthcare facilities

High temperature alarm includes NIST calibrated external temperature readout (NIST certificate included)

Product Features:

Vaccine refrigerator	Purpose-built to meet the recommendations of the CDC and VFC for reliable vaccine storage
ADA compliant	Sized just under 32" high to allow installation under lower ADA compliant counters
Built-in capable	Front-breathing system allows the unit to be installed under cabinets with minimum clearance
Slim 20" width	Full 2.65 cu.ft. capacity inside conveniently slim footprint
Step-to-open door pedal	Helps lessen germ spread by providing a more sanitary method of opening appliance doors, while allowing efficient access to the unit's interior for added convenience
High/low temperature alarm	Audible alarm sounds if the interior temperature rises or falls out of set range
NIST calibrated external temperature display	Alarm includes continuous NIST calibrated display of the current interior and high/low temperature, and can be switched from Celsius to Fahrenheit at the touch of a button
Certificate of calibration included	Calibrated to NIST standards in our ISO/IEC 17025:2017 accredited laboratory, with a certificate included for your records
Digital thermostat	Digital microprocessor for easy and precise temperature management, with all controls externally located for added convenience

ACR45LCALSTO Specifications:

Overview	
Height of Cabinet	31.5" (80 cm)
Width	19.5" (50 cm)
Depth	24.75" (63 cm)
Depth with Handle	23.63" (60 cm)
Depth with door at 90°	41.0" (104 cm)
Capacity	2.65 cu.ft. (75 L)
Defrost Type	Frost-Free
Door	White
Cabinet	White
US Electrical Safety	ETL
Canadian Electrical Safety	ETL-C
Amps	1.0
Voltage/Frequency	115 V AC/60 Hz
Weight	79.0 lbs. (36 kg)
Shipping Weight	110.0 lbs. (50 kg)
Parts & Labor Warranty	1 Year
Compressor Warranty	5 Years
UPC	761101076119

Refrigerator Features	
Door Swing	RHD
Reversible	Factory Reversible
Shelf Type	Wire
Shelf Qty	3
Adjustable Shelves	Yes
Thermostat Type	Digital
Fan Type	Interior and Exterior
Refrigerant Type	R600a
Refrigerant Amount	0.99oz.
High Side PSI	270.0
Low Side PSI	105.0
Level Legs Qty	4
Interior Light	Yes
Temperature Range	2° to 8°C

Dimensions	
Interior Height	21.25" (54 cm)
Interior Width	15.0" (38 cm)
Interior Depth	16.13" (41 cm)

Compressor Step Height	3.5" (9 cm)
Compressor Step Width	15.0" (38 cm)
Compressor Step Depth	4.75" (12 cm)

