

FFAR23LGP



20.75" x 18.75" x 17.5" (H x W x D)

Compact 1.7 cu.ft. general purpose all-refrigerator in white with automatic defrost, front lock, and flat door liner

Highlights:

Perfectly sized for countertop use in healthcare facilities

Automatic defrost for easy user maintenance

Factory-installed lock provides security you can depend on

Product Features:

| | |
|---|--|
| Healthcare refrigerator | Designed for general purpose storage in institutional facilities |
| Countertop dimensions | Slim width and compact depth for easy placement on counters |
| Automatic defrost | Reduced maintenance with auto defrost system |
| Internal fan | Fan-forced cooling helps to keep the temperature more stabilized throughout the interior |
| Adjustable thermostat | Dial thermostat located inside unit for easy temperature management, with an operating range between 1 and 10°C |
| Front-mounted lock | Keyed lock for a secure interior (2 keys included) |
| Hospital grade cord with 'green dot' plug | Secure three-pronged cord for added unit safety in high traffic areas |
| LED lighting | Interior light for efficient illumination with an easy on/off rocker switch |
| Flat door liner | Allows the interior to store deeper items, while also providing improved temperature performance by eliminating hot spots commonly found in door shelves |

FFAR23LGP Specifications:

| Overview | |
|----------------------------|-------------------|
| Height of Cabinet | 20.25" (51 cm) |
| Height to Hinge Cap | 20.75" (53 cm) |
| Width | 18.75" (48 cm) |
| Depth | 17.5" (44 cm) |
| Depth with door at 90° | 35.0" (89 cm) |
| Capacity | 1.7 cu.ft. (48 L) |
| Defrost Type | Automatic |
| Door | White |
| Cabinet | White |
| US Electrical Safety | ETL |
| Canadian Electrical Safety | ETL-C |
| Amps | 1.0 |
| Voltage/Frequency | 115 V AC/60 Hz |
| Weight | 36.0 lbs. (16 kg) |
| Parts & Labor Warranty | 1 Year |
| Compressor Warranty | 5 Years |
| Refrigerator Features | |
| Door Swing | RHD |
| Reversible | No |
| Shelf Type | Wire |
| Shelf Qty | 1 |
| Thermostat Type | Dial |
| Refrigerant Type | R600a |
| Refrigerant Amount | 0.57oz. |
| High Side PSI | 180.0 |
| Low Side PSI | 56.0 |
| Level Legs Qty | 2 |
| Interior Light | Yes |
| Temperature Range | 1 to 10°C |
| Dimensions | |
| Interior Height | 16.25" (41 cm) |
| Interior Width | 15.5" (39 cm) |
| Interior Depth | 12.25" (31 cm) |
| Compressor Step Height | 7.0" (18 cm) |
| Compressor Step Width | 15.5" (39 cm) |
| Compressor Step Depth | 6.5" (17 cm) |

